



EUROPEAN SOUTHERN OBSERVATORY

Organisation Européenne pour des Recherches Astronomiques dans l'Hémisphère Austral
Europäische Organisation für astronomische Forschung in der südlichen Hemisphäre

LA SILLA OBSERVATORY

2P2 TCS Software Drivers

Doc. No.: 2P2-MAN-ESO-60100-0001

Issue: 1.1

Date: 3-April-2000

Prepared: J. Alonso

Name

Date

Signature

Approved: G. Andreoni

Name

Date

Signature

Released: G. Andreoni

Name

Date

Signature

CHANGE RECORD

Revision	Date	Section/Paragraph	Remarks
Issue 1.0	13/8/1998	All	First Issue
Issue 1.1	3/4/2000	Several	Feedback from FRI + revision by JAL

1. INTRODUCTION	5
1.1. PURPOSE AND SCOPE.....	5
1.2. REFERENCE AND APPLICABLE DOCUMENTS	5
1.3. ACRONYMS AND ABBREVIATIONS	5
2. TCM_INITIALIZE()	5
3. INITIALIZE()	6
4. POSITION()	7
5. PRESET()	7
6. MODE()	9
7. TRACK()	9
8. HANDSET()	10
9. FOCUS_PRESET()	11
10. FOCUS_POSITION()	12
11. MIRROR()	12
12. ROTATOR_POSITION()	13
13. SIDEREAL_TIME_SYNC()	13
14. HOURS() MINUTES() SECONDS()	14
15. DOMEPOS()	14
16. DOMESET()	15
17. DOMESTAT()	15
18. DOMESTOP()	16
19. SLITOPEN()	16
20. SLITCLOSE()	17
21. SLITSTOP()	17
22. SLITSTAT()	18
23. UPWSPOS()	18
24. UPWSSET()	19
25. UPWSSTOP()	19
26. UPWSSTAT()	20

27.	 LOWSP0S()	20
28.	 LOWSET()	21
29.	 LOWSTOP()	21
30.	 LOWSTAT()	22
31.	 SLWSTAT()	22
32.	 READ_ENVIRONMENT()	23
33.	 N2_MODE_MANUAL()	24
34.	 N2_MODE_AUTOMATIC()	25
35.	 N2_OPEN()	25
36.	 N2_CLOSE()	26
37.	 N2_STATUS()	26
38.	 APPENDIX	28
38.1.	MAIN DRIVE CONSTANTS.....	28
38.1.1.	<i>Alpha</i>	28
38.1.2.	<i>Delta</i>	28
38.2.	FOCUS DRIVE CONSTANTS	28

1. INTRODUCTION

1.1. PURPOSE AND SCOPE

This document contains the prototypes together with a description of all the functions written under vxWorks for controlling the 2p2 meter telescope. Among these functions are included the auxiliary system and environmental sensing.

1.2. REFERENCE AND APPLICABLE DOCUMENTS

- 1 Telescope Control Module TCM (Hardware schematics)

1.3. ACRONYMS AND ABBREVIATIONS

BCD	Binary Coded Decimal
TCMDIG	Telescope Control Module Digital
TCMANA	Telescope Control Module Analogue
LCU	Local Control Unit
CPU	Central Processing Unit

2. TCM_Initialize()

NAME

TCM_Initialize() - hardware initialisation

SYNOPSIS

STATUS TCM_Initialize(void);

DESCRIPTION

This function checks the various hardware subsystems initialising the axis motion processors together with the associated peripherals within the TCMDIG and TCMANA.

RETURNS

OK or ERROR

ERRNO

S_tcsLib_ALPHA_ROD260_MALFUNCTION
Self explanatory
S_tcsLib_DELTA_ROD260_MALFUNCTION
Self explanatory

CAVEATS

The state of the TCM is reflected by a global variable of the enumerated type **modstat**. After the TCMDIG initialisation the state should be **Analog** or **Digital** and the **TCM_Initialize()** function should return **OK**. In case of problems the state remains **TCM_not_initialize** and the pertinent error number is set returning **ERROR**.

3. Initialize()

NAME

Initialize() - axis initialisation

SYNOPSIS

STATUS Initialize(axis)
ax axis; /* 0 alpha, 1 delta */

DESCRIPTION

This function initialises the specified axis. The initialisation procedure is accomplished in three stages;

- 1- Performs all the error checking (TCMDIG initialisation, TCM mode, power amplifiers on state and the axis absolute position) and defines the actual position as home position, enables the reference point interrupt detection and moves the axis very far away.
- 2- Starts when the reference point interrupt is detected. The axis is instructed to decelerate and stop, a move is done to the exact reference point and the reference point is defined as home position.
- 3- The absolute position is measured and a preset is done to the absolute zero position, then a offset is added, if specified, by presetting the axis and defining the zero position again.

RETURNS

OK or ERROR

ERRNO

S_tcsLib_VALUE_OUT_OF_RANGE

The specified axis does not exist.

S_tcsLib_TCM_NOT_INITIALIZED

Self explanatory

S_tcsLib_TCM_ANALOG_MODE

Self explanatory

S_tcsLib_ALPHA_PRESET_IN_PROGRESS

Re-initialisation can only be requested in **track** and **slew** modes.

S_tcsLib_DELTA_PRESET_IN_PROGRESS

Same as alpha

S_tcsLib_INIT_NOT_ALLOWED_AT_MORE_THAN_45_DEG

One or both axis are inclined more than 45deg. from zenith position.

S_tcsLib_ALPHA_DRIVE_KEPCO_POWER_OFF

Self explanatory

S_tcsLib_DELTA_DRIVE_KEPCO_POWER_OFF

Self explanatory

S_tcsLib_ALPHA_PRELOAD_KEPCO_POWER_OFF

Self explanatory

S_tcsLib_DELTA_PRELOAD_KEPCO_POWER_OFF

Self explanatory

CAVEATS

The state of the particular axis is reflected by a global variable of the enumerated type **axstat**. After the axis initialisation the state should change from **init** to **slew** and the **Initialize()** function returns **OK**. In case of an error occurrence there are two possibilities:

- 1- The state does not change and the **Initialize()** function sets the pertinent error number in the execution context (e.g. the vxWorks shell) and returns **ERROR**.
- 2- The **Initialize()** function returns **OK** and the state remains **init** several seconds but suddenly the state goes back to **not_initialized**. In this case the error number could be imported to the execution context by using **errnoOfTaskGet()** from **init1_alpha_ID** and/or **init1_delta_ID**.

4. Position()

NAME

Position() - read axis position

SYNOPSIS

```
int Position(axis)
ax axis; /* 0 alpha, 1 delta */
```

DESCRIPTION

This function reads the absolute position of the specified axis. It is possible to call this function up to 1000 times per second when the low - level drivers are alone in the LCU. However the calling rate is limited by higher level programs running together in the LCU.

RETURNS

An integer value representing the actual axis position.

ERRNO

N/A

CAVEATS

The position value is only meaningful if the axis is initialised. When the axis is not initialised the returned value is always zero.

5. Preset()

NAME

Preset() - move the axis to a specified position

SYNOPSIS

```
STATUS Preset(axis, pos, vel)  
    ax axis; /* 0 alpha, 1 delta */  
    int pos; /* position */  
    int vel; /* speed */
```

DESCRIPTION

This function loads position and speed in the axis control processor, and then starts the motion of the specified axis. It is valid to call this function during **preset**, **track** and **slew** axis states up to 1000 times per second. At the end of a successful move the status should change from **preset** to **slew**. If the move fails the status should change from **preset** to **not_initialized**.

RETURNS

OK or ERROR.

ERRNO

```
S_tcsLib_VALUE_OUT_OF_RANGE  
    The specified axis does not exist.  
S_tcsLib_TCM_NOT_INITIALIZED  
    Self explanatory  
S_tcsLib_TCM_ANALOG_MODE  
    Self explanatory  
S_tcsLib_ALPHA_AXIS_NOT_INITIALIZED  
    Self explanatory  
S_tcsLib_ALPHA_SLEW_SPEED_OUT_OF_RANGE  
    Specified vel is greater than servo1.max_slew_speed  
S_tcsLib_DELTA_AXIS_NOT_INITIALIZED  
    Self explanatory  
S_tcsLib_DELTA_SLEW_SPEED_OUT_OF_RANGE  
    Specified vel is greater than servo2.max_slew_speed  
S_tcsLib_ALPHA_DRIVE_KEPCO_POWER_OFF  
    Self explanatory  
S_tcsLib_DELTA_DRIVE_KEPCO_POWER_OFF  
    Self explanatory  
S_tcsLib_ALPHA_PRELOAD_KEPCO_POWER_OFF  
    Self explanatory  
S_tcsLib_DELTA_PRELOAD_KEPCO_POWER_OFF  
    Self explanatory
```

CAVEATS

In the error occurrence case there are two possibilities:

- 1- The state of the axis does not change and the **Preset()** function sets the pertinent error number in the context of the calling task (e.g. the vxWorks shell) and returns **ERROR**.
- 2- **Preset()** returns **OK** and the axis state remains **preset** several seconds but suddenly the state change to **not_initialized**. In this case the error number must be imported to the execution context using **errnoOfTaskGet()** from **pos_err_al_ID** for alpha and **pos_err_de_ID** for delta.

6. Mode()

NAME

Mode() – track/slew modes selection

SYNOPSIS

```
STATUS Mode(axis, mode)
    ax axis; /* 0 alpha, 1 delta */
    mod mode; /* 0 SLEW, 1 TRACK */
```

DESCRIPTION

This function selects the track and slew operation modes for a particular axis.

RETURNS

OK or ERROR.

ERRNO

S_tcsLib_VALUE_OUT_OF_RANGE
The specified axis does not exist.

S_tcsLib_TCM_NOT_INITIALIZED
Self explanatory

S_tcsLib_TCM_ANALOG_MODE
Self explanatory

S_tcsLib_ALPHA_AXIS_NOT_INITIALIZED
Self explanatory

S_tcsLib_ALPHA_PRESET_IN_PROGRESS
During preset the mode can not be changed to track.

S_tcsLib_DELTA_AXIS_NOT_INITIALIZED
Self explanatory

S_tcsLib_DELTA_PRESET_IN_PROGRESS
During preset the mode can not be changed to track.

CAVEATS

A preset can be aborted by **Mode(axis,SLEW)**, after executing, the particular axis will decelerate and stop.

7. Track()

NAME

Track() - changes tracking velocity

SYNOPSIS

```
STATUS Track(axis, vel)  
    ax axis; /* 0 alpha, 1 delta */  
    int vel; /* velocity */
```

DESCRIPTION

This function allows change the tracking velocity of the specified axis. It is particularly useful for applying offsets or minute changes in position.

RETURNS

OK or ERROR.

ERRNO

S_tcsLib_VALUE_OUT_OF_RANGE

The specified axis does not exist.

S_tcsLib_TCM_NOT_INITIALIZED

Self explanatory

S_tcsLib_TCM_ANALOG_MODE

Self explanatory

S_tcsLib_ALPHA_AXIS_NOT_INITIALIZED

Self explanatory

S_tcsLib_ALPHA_TRACK_SPEED_OUT_OF_RANGE

The absolute value of **vel** is greater than **servo1.max_track_speed**

S_tcsLib_ALPHA_TRACK_MODE_NOT_SELECTED

Self explanatory

S_tcsLib_DELTA_AXIS_NOT_INITIALIZED

Self explanatory

S_tcsLib_DELTA_TRACK_SPEED_OUT_OF_RANGE

The absolute value of **vel** is greater than **servo2.max_track_speed**

S_tcsLib_DELTA_TRACK_MODE_NOT_SELECTED

Self explanatory

CAVEATS

Please refer to the appendix for the allowed maximum tracking velocity.

8. Handset()

NAME

Handset() - reads the digital handset

SYNOPSIS

```
int Handset(void);
```

DESCRIPTION

reads the digital handset port.

RETURNS

An integer with the following bit distribution;

0 = delta -

1 = delta +

2 = alpha -

3 = alpha +

4 = guide

5 = offset

6 = set

7 - 31 = don't care

ERRNO

N/A

CAVEATS

N/A

9. Focus_preset()**NAME**

Focus_preset() – Moves M2 mirror to a specified position

SYNOPSIS

```
STATUS Focus_preset(pos)
int pos;
```

DESCRIPTION

This function presets the M2 mirror to any position within the allowed range. Please refer to the appendix for the actual range and limit numbers.

RETURNS

OK or ERROR.

ERRNO

S_tcsLib_FOCUS_PRESET_ACTIVE

Before instructing a new motion the focus mechanism must be on position.

S_tcsLib_VALUE_OUT_OF_RANGE

The number specified is outside the software limits.

S_tcsLib_FOCUS_UPPER_LIMIT

The mechanism is on the hardware limit.

S_tcsLib_FOCUS_LOWER_LIMIT

The mechanism is on the hardware limit.

CAVEATS

The software limits are set slightly before the hardware limits, this means that the upper and lower hardware limits should never be reached under normal operation.

The sole function of the hardware limits is protection against catastrophic malfunctions. The upper and lower limit values are specified in the appendix of this document.

10. Focus_position()

NAME

Focus_position() – returns the focus position

SYNOPSIS

STATUS Focus_position(void);

DESCRIPTION

This function returns the M2 mirror position.

RETURNS

OK or ERROR

ERRNO

S_tcsLib_FOCUS_UPPER_LIMIT

On the hardware limit

S_tcsLib_FOCUS_LOWER_LIMIT

On the hardware limit

CAVEATS

The software limits are set slightly before the hardware limits, this means that the upper and lower hardware limits should never be reached under normal operation. The sole function of the hardware limits is protection against catastrophic malfunctions. The upper and lower limit values are specified in the appendix of this document.

11. Mirror()

NAME

Mirror() – open and close the main mirror cover

SYNOPSIS

mirstat Mirror(action)

miract action; /* 0 mclose, 1 mopen, 2 mstatus */

DESCRIPTION

This function opens, close and gets the M1 main mirror cover status.

RETURNS

An enumerated variable of the type **mirstat**

Typedef enum {moving, closed, opened, ok, error, local} **mirstat**

ERRNO

S_tcsLib_MIRROR_COVER_MECHANICAL_PROBLEM

This message indicates that the main mirror cover mechanism got stuck and/or a limit switch failed.

CAVEATS

N/A

12. Rotator_position()

NAME

Rotator_position() – returns the rotator position

SYNOPSIS

```
STATUS Rotator_position(position)  
char *position[];
```

DESCRIPTION

This function delivers the rotator position in a character string. A pointer to a string of at least 10 characters must be passed.

RETURNS

OK

ERRNO

N/A

CAVEATS

The rotator's position is delivered in degrees with a precision and warranted accuracy of a tenth of a degree.

13. Sidereal_time_sync()

NAME

Sidereal_time_sync() – returns the sidereal time from the Cerme clock

SYNOPSIS

```
int Sidereal_time_sync(void)
```

DESCRIPTION

This function waits for synchronisation with the next sidereal second and reads the Cerme clock.

RETURNS

An integer containing the seconds, minutes and hours in BCD format. The seconds comes on the least significant byte and so on.

ERRNO

N/A

CAVEATS

Because this function is used for synchronisation purposes it should be called bearing in mind that uses 100% of the CPU for a maximum time of 1 second.

14. Hours() Minutes() Seconds()**NAME**

Hours()

Minutes()

Seconds() – functions for reading hours, minutes and seconds

SYNOPSIS

int Hours(void);

int Minutes(void);

int Seconds(void);

DESCRIPTION

Three non-blocking functions for reading sidereal hours, minutes and seconds from the Cerme clock.

RETURNS

An integer with the, hours minutes or seconds. BCD coded in the least significant byte.

15. Domepos()**NAME**

Domepos() – returns the dome position

SYNOPSIS

int Domepos(void);

DESCRIPTION

This function reads and returns the dome azimuth. The dome micro controller is interrogated by the function via the RS-232 port 4 of the LCU's MV167 CPU.

RETURNS

An integer with the dome azimuth coded from 0 to 999 for the 0 to 360 degrees positions.

ERRNO

S_tcsLib_DOME_u_CONTROLLER_NOT_RESPONDING
dome u controller malfunction or power fail

CAVEATS

N/A

16. Domeset()**NAME**

Domeset() – presets the dome to the specified position

SYNOPSIS

```
int Domeset(pos)
int pos;
```

DESCRIPTION

This function presets the dome to the specified azimuth of 0 to 999 which corresponds to 0 to 360 degrees. The command is sent to and the answer received from the dome micro controller via the RS-232 port 4 of the LCU's MV167 CPU.

RETURNS

OK or ERROR

ERRNO

S_tcsLib_VALUE_OUT_OF_RANGE
The specified value is not in the range 0 to 999

CAVEATS

N/A

17. Domestat()**NAME**

Domestat() – returns the dome status

SYNOPSIS

```
dome_status Domestat(void);
```

DESCRIPTION

This function gets and returns the dome status. The command is sent to and the answer received from the dome micro controller via the RS-232 port 4 of the LCU's MV167 CPU.

RETURNS**A dome_status**typedef enum {DLOCAL, DREMOTE, DMOVING} **dome_status;****ERRNO****S_tcsLib_DOME_u_CONTROLLER_NOT_RESPONDING**

Dome micro controller not responding or power fail

S_tcsLib_UNKNOWN_STATUS_RECEIVED

Self explanatory

CAVEATS

N/A

18. Domestop()**NAME****Domestop()** – stops the dome motion**SYNOPSIS****int Domestop(void);****DESCRIPTION**

This function stops the dome motion. The command is sent to the dome micro controller via the RS-232 port 4 of the LCU's MV167 CPU.

RETURNS

OK

CAVEATS

N/A

19. Slitopen()**NAME****Slitopen()****SYNOPSIS****int Slitopen(void);****DESCRIPTION**

This function opens the dome slit. The command is sent to the slit micro controller via the RS-232 port 3 of the LCU's MV167 CPU.

RETURNS

OK

ERRNO

N/A

CAVEATS

N/A

20. Slitclose()**NAME****Slitclose()** – closes the dome slit**SYNOPSIS****int Slitclose(void);****DESCRIPTION**

This function closes the dome slit. The command is sent to the slit micro controller via the RS-232 port 3 of the LCU's MV167 CPU.

RETURNS

OK

ERRNO

N/A

CAVEATS

N/A

21. Slitstop()**NAME****Slitstop()** – stops the slit motion**SYNOPSIS****int Slitstop(void);****DESCRIPTION**

This function stops the dome slit motion. The command is sent to the slit micro controller via the RS-232 port 3 of the LCU's MV167 CPU.

RETURNS

OK

ERRNO

N/A

CAVEATS

N/A

22. Slitstat()

NAME

Slitstat() – returns the slit status

SYNOPSIS

slit_status Slitstat(void);

DESCRIPTION

This function reads and returns the slit status. The command is sent to and the answer is received from the slit micro controller via the RS-232 port 3 of the LCU's MV167 CPU.

RETURNS

A **slit_status**

typedef enum {SOPEN, SLCLOSED, SLMOVING, SLSTOP} **slit_status;**

ERRNO

S_tcsLib_SLIT_WSCR_u_CONTROLLER_NOT_RESPONDING

Slit micro controller malfunction or power fail

S_tcsLib_UNKNOWN_STATUS_RECEIVED

Self explanatory

CAVEATS

N/A

23. Upwspos()

NAME

Upwspos() – returns the upper wind screen position

SYNOPSIS

int Upwspos(void);

DESCRIPTION

This function reads and returns the upper wind screen position, the valid range of positions is from 0 to 999. The command is sent to and the answer received from the slit micro controller via RS-232 port 3 of the LCU's MV167 CPU.

RETURNS

An integer with the upper wind screen position.

ERRNO

S_tcsLib_SLIT_WSCR_u_CONTROLLER_NOT_RESPONDING

Dome micro controller malfunction or power fail

CAVEATS

N/A

24. Upwsset()**NAME**

Upwsset() – sends the upper wind screen to the specified position

SYNOPSIS

```
int Upwsset(pos)
int pos;
```

DESCRIPTION

This function sends the upper windscreen to the specified position. The valid range of positions is from 0 to 999. The command is sent to the slit micro controller via RS-232 port 3 of the LCU's MV167 CPU.

RETURNS

OK or ERROR

ERRNO

S_tcsLib_VALUE_OUT_OF_RANGE

The specified value is not in the range 0 to 999

CAVEATS

N/A

25. Upwsstop()**NAME**

Upwsstop() – stops the upper windscreen motion

SYNOPSIS

```
int Upwsstop(void);
```

DESCRIPTION

This function stops the upper windscreen motion. The command is sent to the slit micro controller via the RS-232 port 3 of the LCU's MV167 CPU.

RETURNS

OK

ERRNO

N/A

CAVEATS

N/A

26. Upwsstat()

NAME

Upwsstat() – reads the upper windscreen status

SYNOPSIS

```
upper_wscr_status Upwsstat(void);
```

DESCRIPTION

This function gets and returns the upper windscreen status. The command is sent to and the answer received from the slit micro controller via the RS-232 port 3 of the LCU's MV167 CPU.

RETURNS

A **upper_wscr_status**

```
typedef enum {UWSMOVING, UWSSTOP} upper_wscr_status
```

ERRNO

S_tcsLib_SLIT_WSCR_u_CONTROLLER_NOT_RESPONDING

Dome micro controller malfunction or power fail

S_tcsLib_UNKNOWN_STATUS_RECEIVED

Self explanatory

CAVEATS

N/A

27. Lowspos()

NAME

Lowspos() – reads the lower wind screen position

SYNOPSIS

```
int Lowspos(void);
```

DESCRIPTION

This function reads and returns the lower wind screen position, the valid range of positions is from 0 to 999. The command is sent and the answer received from the slit micro controller via the RS-232 port 3 of the LCU's MV167 CPU.

RETURNS

An integer with the position

ERRNO

S_tcsLib_SLIT_WSCR_u_CONTROLLER_NOT_RESPONDING

Dome micro controller malfunction or power fail

CAVEATS

N/A

28. Lowsset()**NAME**

Lowsset() – sends the lower wind screen to the specified position

SYNOPSIS

```
int Lowsset(pos)  
int pos;
```

DESCRIPTION

This function sends the lower windscreen to the specified position. The valid range of positions is from 0 to 999. The command is sent to the slit micro controller via the RS-232 port 3 of the LCU's MV167 CPU.

RETURNS

OK or ERROR

ERRNO

S_tcsLib_VALUE_OUT_OF_RANGE

The specified value is not in the range 0 to 999

CAVEATS

N/A

29. Lowsstop()**NAME**

Lowsstop()

SYNOPSIS

```
int Lowsstop(void);
```

DESCRIPTION

This function stops the lower windscreen motion. The command is sent to the slit micro controller via the RS-232 port 3 of the LCU's MV167 CPU.

RETURNS

OK

ERRNO

N/A

CAVEATS

N/A

30. Lowsstat()**NAME****Lowsstat()** – reads the upper windscreen status**SYNOPSIS****lower_wscr_status Lowsstat(void);****DESCRIPTION**

This function reads and returns the lower windscreen status. The command is sent to and the answer received from the slit micro controller via the RS-232 port 3 of the LCU's MV167 CPU.

RETURNSA **lower_wscr_status**typedef enum {LWSMOVING, LWSSTOP} **lower_wscr_status;****ERRNO****S_tcsLib_SLIT_WSCR_u_CONTROLLER_NOT_RESPONDING**

Dome micro controller malfunction or power fail

S_tcsLib_UNKNOWN_STATUS_RECEIVED

Self explanatory

CAVEATS

N/A

31. Slwsstat()**NAME****Slwsstat()** – reads the slit and windscreen status**SYNOPSIS****slit_wscr_status Slwsstat(void);****DESCRIPTION**

This function reads and returns the slit and windscreen system status. The command is sent to and the answer received from the slit micro controller via the RS-232 port 3 of the LCU's MV167 CPU.

RETURNS**A slit_wscr_status**typedef enum {SLWSLOCAL, SLWSREMOTE} **slit_wscr_status;****ERRNO****S_tcsLib_SLIT_WSCR_u_CONTROLLER_NOT_RESPONDING**

Dome micro controller malfunction or power fail

S_tcsLib_UNKNOWN_STATUS_RECEIVED

Self explanatory

CAVEATS

N/A

32. Read_environment()**NAME****Read_environment()** – reads the 16 environmental sensors**SYNOPSIS****STATUS Read_environment(temp)****temp_humi *temp;****DESCRIPTION**

This function delivers the readout of 16 analogue channels associated to the temperature and humidity sensors distributed all over the telescope and building. A pointer to a structure of the type **temp_humi** must be passed to the function.

```
typedef struct{
    char T_sensor1[10];
    char T_sensor2[10];
    char T_sensor3[10];
    char T_sensor4[10];
    char T_sensor5[10];
    char T_sensor6[10];
    char T_sensor7[10];
    char T_sensor8[10];
    char T_sensor9[10];
    char T_sensor10[10];
    char T_sensor11[10];
    char T_sensor12[10];
    char T_sensor13[10];
    char T_sensor14[10];
    char T_sensor15[10];
    char T_sensor16[10];
} temp_humi;
```

RETURNS

OK

ERRNO

N/A

CAVEATS

The physical position of the sensors is as follows:

- 1- Air temperature outside south of the dome in shadow.
- 2- Air temperature outside north of the dome, road heat sensor.
- 3- Air temperature at low level in dome near floor.
- 4- Surface temperature of main mirror.
- 5- Air temperature close to the main mirror surface.
- 6- Surface temperature mid height of the lower Serrurier.
- 7- Surface temperature mid height of the upper Serrurier.
- 8- Surface temperature of the secondary mirror.
- 9- Air temperature close to the top ring.
- 10- Plate temperature sensor looking into the sky at the top ring.
- 11- Air temperature inside the dome at mid height.
- 12- Air temperature for the instrument.
- 13- Surface temperature of the delta hydrostatic pad.
- 14- Air temperature inside the adapter.
- 15- Outside relative humidity close to temperature sensor number 1.
- 16- Inside relative humidity close to temperature sensor number 11.

Worth to mention that by giving the command "**denv**" at the vxWorks shell a listing of the 16 sensor values is displayed on screen.

33. N2_mode_manual()**NAME**

N2_mode_manual() – sets the N2 gas flushing to manual mode

SYNOPSIS

STATUS N2_mode_manual(void);

DESCRIPTION

This function forces the N2 gas flushing for the mosaic window to manual allowing the opening and closing of the valve by using **N2_open()** or **N2_close()**. At boot time a task is created to check the relative humidity at the dome, for humidity values $H \geq 60\%$ the valve is opened and for $H \leq 50\%$ the valve is closed automatically by the task. The default state for the mentioned task at creation time is "automatic", when the task is forced to manual by using **N2_mode_manual()** a warning message is issued to the standard out every 10 seconds.

RETURNS

OK

ERRNO

N/A

CAVEATS

N/A

34. N2_mode_automatic()**NAME****N2_mode_automatic()** – sets the N2 gas flushing to automatic mode**SYNOPSIS****STATUS N2_mode_automatic(void);****DESCRIPTION**

This function returns the N2 flushing system to default state "automatic".

RETURNS

OK

ERRNO

N/A

CAVEATS

N/A

35. N2_open()**NAME****N2_open()** – opens the N2 gas valve.**SYNOPSIS****STATUS N2_open(void);****DESCRIPTION**

This function manually opens the N2 gas valve for flushing the mosaic window.

RETURNS

OK or ERROR

ERRNOThe message "Please set N2mode to manual" is sent to the standard out and ERROR is returned if the mode is "automatic" when the **N2_open()** is issued.

CAVEATS

N/A

36. N2_close()**NAME**

N2_close() – closes the N2 gas valve.

SYNOPSIS

STATUS N2_close(void);

DESCRIPTION

The same as **N2_open** but for closing the valve

RETURNS

OK or ERROR

ERRNO

The same as **N2_open**

CAVEATS

N/A

37. N2_status()**NAME**

N2_status(void) – displays the state of the N2 flushing system

SYNOPSIS

STATUS N2_status(void);

DESCRIPTION

This function displays the state of the N2 flushing system. Four states are possible:

- 1- "N2 valve is closed"
- 2- "N2 supply set to manual"
- 3- "N2 valve is open"
- 4- "N2 supply set to automatic"

The pertinent message is sent to the standard out.

RETURNS

OK

ERRNO

N/A

SOFTWARE DRIVERS

2P2 TCS Software Drivers

3-April- 2000
Doc. 2P2-MAN-ESO-60100-1

CAVEATS

N/A

38. APPENDIX

38.1. *Main Drive Constants*

38.1.1.Alpha

Resolution = 0.0036 arcsec

Backlash = 28 X 0.0036 arcsec

Maximum Velocity = +/-3600 arcsec/sec (TCMDIG setting = +/- 21500000)

Acceleration = +/- 400 arcsec/sec*sec (fixed)

Tracking Velocity = 15.04106777 arcsec/sec (TCMDIG setting = 91288)

Maximum Tracking Velocity = +/-75.2 arcsec/sec (TCMDIG setting = +/-456440)

38.1.2.Delta

Resolution = 0.0036 arcsec

Backlash = 65 X 0.0036 arcsec

Maximum Velocity = +/-3600 arcsec/sec (TCMDIG setting = +/- 21500000)

Acceleration = +/- 400 arcsec/sec*sec (fixed)

Maximum Tracking Velocity = +/-75.2 arcsec/sec (TCMDIG setting = +/-456440)

38.2. *Focus Drive Constants*

Focus Range = 31.73mm

Upper Limit = 29140

Lower Limit = 3758

Resolution = 1.25 microns

Approximate focus position for the old adapter+CCD = 20099