

ISER8 – BOARD CONNECTIONS

CONNECTOR P2			FRONT PANEL			COMMENTS
Pin #	RS232	RS485	CANNON 9-Fem.	LEMO 0:2	Channel	
28a	GND	-	5	-	1	
27a	DTR	-	4	-	1	
27c	CTS	-	8	-	1	
26a	TxD	-	3	-	1	
25a	RxD	-	2	-	1	
25c	GND	-	5	-	2	
24c	DTR	-	4	-	2	
23a	CTS	-	8	-	2	
23c	TxD	-	3	-	2	
22c	RxD	-	2	-	2	
21a	GND	-	5	-	3	
20a	DTR	-	4	-	3	
20c	CTS	-	8	-	3	
19a	TxD	-	3	-	3	
18a	RxD	-	2	-	3	
18c	GND	-	5	-	4	
17c	DTR	-	4	-	4	
16a	CTS	-	8	-	4	
16c	TxD	-	3	-	4	
15c	RxD	-	2	-	4	
14a	GND	-	5	-	5	
13a	DTR	-	4	-	5	
13c	CTS	-	8	-	5	
12a	TxD	-	3	-	5	
11a	RxD	-	2	-	5	
11c	GND	-	5	-	6	
10c	DTR	-	4	-	6	
9a	CTS	-	8	-	6	
9c	TxD	-	3	-	6	
8c	RxD	-	2	-	6	
7a	GND	-	5	-	7	
6a	DTR	-	4	-	7	
6c	CTS	-	8	-	7	
5a	TxD	-	3	-	7	
4a	RxD	-	2	-	7	

